




Assembly Instructions - Siesta

Models
Classic/Trio/Fiora

LK Hjelle



Congratulations!



Siesta is the perfect choice

Gratulerer!

Siesta er det perfekte valget

Architect Ingmar Relling received in 1965 The Norwegian Bransjeraadets Price for Siesta. One year later Siesta received its first design price.

Arkitekt Ingmar Relling mottok i 1965 Det Norske Bransjerådets Pris for Siesta. Ett år senere fikk Siesta sin første designpris.

Siesta is recognized worldwide as a worthy exponent for Scandinavian Design and has received several international awards for its clean design and its first-class quality.

Siesta er anerkjent over hele verden som en verdig kandidat for Skandinavisk Design og har mottatt flere internasjonale priser for sin rene design og førsteklasses kvalitet.

You will be able to enjoy the comfort, the clean design and the superb quality of your Siesta for years to come

Du vil nå få nyte komfort, ren design og den flotte kvaliteten på din Siesta i årene som kommer.

Ingmar Relling

LK Hjelle Møbelfabrikk AS
Postboks 8, N-6230 Sykkylven
Phone: +47 70 25 44 00
E-mail: office@hjelle.no

www.hjelle.no



LK Hjelle



Assembly Instructions

1

Verify you have all the pieces shown



2

Place the chair on a protective pad on the floor. Bolt the straight crossbar between and to the lowest lying laminate side with 2 bolts without tightening.



3

Remove the rubber band and unscrew the 2 bolts.



4

Bolt the two curved crossbars to the lowest lying laminate side to the top of the back and the seat – 1 bolt each place.



5

Put your foot on the lowest lying laminate side and pull the top laminate side up in position.



6

Bolt the straight crossbar to the top laminate side in the upper hole – only 1 bolt for now.



7

Put your foot on the lowest lying frame side and pull the top opposite side up until you can press the curved crossbars into the 2 metal dowels under the seat and behind the back. Then put in the bolts.



8

Now put the last bolt into the straight crossbar and the top laminate side. You may use a rubber hammer to get the bolt through the hole. Adjust the hole by pulling the top laminate side.



9

Bolt the armrest to the back without fully tightening.



10

Pull the armrest over the front part of the arm frame – attach the bolt in from the inside.



11

Tighten all the bolts. Remember to occasionally tighten all bolts.



12

Take a Siesta!



Removal of stains



If the wood has got spots or stains, one should always first try to remove them with a cloth wrung in lukewarm water and if necessary with a mild detergent.

Soap treated surfaces

Difficult grease/ oil spots	Remove with purified gasoline and light sanding with fine sandpaper. The same treatment for stains of stearin.
Pen/marker	Can be removed with a soft cloth soaked in alcohol.
Dark spots	From such as newspaper or shoe polish, can be removed with an eraser or fine sandpaper.
Deep marks/dents	Requires sanding with sandpaper.
Fire marks	Should be sanded. It is necessary to sand a larger area to avoid as less unevenness in the wood as possible.
Red wine/fruit juice	Can discolor beech and oak so deep, that it might be necessary to bleach the wood. This can be done with 2 parts 36 % hydrogen peroxide diluted with 1 part water. Brush very carefully directly on the stain.
NB!	ANY POLISH/GRINDING MUST BE PERFORMED WITH THE UTMOST CAUTION TO AVOID GRINDING HOLES IN THE VENEER.



Oil treated surfaces

Difficult grease/ oil spots	Can be removed with mineral spirits. Oil treatment should be repeated after use of mineral spirits.
Pen/marker	Can be removed with a soft cloth soaked in alcohol.
Dark spots	From such as newspaper or shoe polish, can be removed with an eraser or fine sandpaper.
Deep marks/dents	Requires sanding with sandpaper.
Fire marks	Should be sanded. It is necessary to sand a larger area to avoid as less unevenness in the wood as possible.
NB!	ANY POLISH/GRINDING MUST BE PERFORMED WITH THE UTMOST CAUTION TO AVOID GRINDING HOLES IN THE VENEER.

Lacquered surfaces

Can be wiped with a damp cloth. If it occurs stains on lacquered surfaces, it is normally caused by worn and porous coating. This requires sanding and refinishing.

WE RECOMMEND YOU TO USE PROFESSIONALS FOR THIS WORK!