

# Timber Table

For best results when cleaning acrylic surfaces, we recommend that you use a **lint-free soft cloth** and **acrylic cleaner**. Avoid using paper towels. Do not use window cleaner or any other alcohol or ammonia-based products, as they may cloud the finish of your table.

**THE TIMBER TABLE IS A DECORATIVE ACCENT TABLE,  
AND SHOULD NOT BE USED AS A SEAT OR STEP.**

