

BDIUSA.COM CUSTOMERSERVICE@BDIUSA.COM

Placement and Maintenance

DINO TABLES are designed for indoor use on level floors. Clean glass with glass cleaner, and shelf with a moist cloth.



Component List

DINO TABLES are engineered for easy assembly. Carefully follow this procedure to prevent any damage. Unpack and identify the components. The assembly workspace should be a non-marring surface such as clean carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com. For all other concerns, please contact your BDI Retailer.



A - Hex Wrench 4mm



B - 1/4-20 x 3/4 Flat Head Screws 4mm Socket Drive x 6



C - 1/4-20 x 1/2 Flat Head Screws 4mm Socket Drive x 3



E - Shelf x 1


F - Glass x 1



G - Felt Pads x 3




H - Felt O-Rings x 3



Step 1 - Attach Legs to Shelf
Place long edge of Shelf (E) on soft surface in order to prevent damage.

Attach Legs (D) to Shelf (E) using Screws (B) and tighten using Hex Drive Wrench (A). Attach first Leg (D) to middle point of Shelf (E).

Optional: If placed on hard floor, attach Felt Pads (G) to bottom of Legs (D).



Step 2 - Attach Glass to Legs Attach Felt O-Rings (H) to Glass Pucks. Turn table up onto Legs (D). Place Glass (F) onto Legs (D). Loosely start all Screws (C) into Glass Fittings. After all Screws (C) are started, then tighten Screws (C) using Hex Drive Wrench (A). Glass Puck D