

Replacing the center triangle or hinges

- Separate the top from the base.
- Open the table and unscrew the 3 bolts with which the tabletop is fitted to the base.
- Lift off the tabletop so that you can get close to the base with the folding leaves.
- Release the 3 leaves. Cover the top half of leaves with a towel or similar to protect the leaves from damage. One person should then pull the leaves halfway up while holding the leaves together. The second person can then tape the 3 leaves together.
- To get the 3 leaves out of the base you lift the triangle above the base top and then you turn the bundle of leaves counterclockwise until the top of the spring comes out of the metal “eyes” that holds it to the underside of the triangle.



When the leaves are separated from the base, remove the tape and place the leaves unfolded on a soft surface/carpet so you don't leave scratches on the leaves.

Untighten each of the screws on the hinges that hold the leaves to the center triangle. (see yellow marking). Slowly wiggle hinge from side to side lifting it out of the triangle/leaf.

Replace the triangle and reattach the hinges onto the new triangle.

Reverse the first steps, to place the leaves back into the base.



Warning: these instructions are ment for a furniture professional with experience in the Skovby product line.