


Assembly & Installation





Stressless® Classic Power Leg*



Classic Power Leg and Back

Classic Power



*Note: for Stressless classic leg models, these buttons are two round metal touch-sensors on the seat cushion located on the right side when seated.





Spare part:
1997333

Warnings

