



LUMA LIFT DESK

QUICK START GUIDE

Your Luma Lift Desk is engineered to provide years of worry-free operation. This guide provides you with basic information for operating your new desk.

See owner's manual for complete details.

SAFETY INFORMATION

- Ensure there are no obstructions in the desk's path (i.e. window sill, shelves)
- Position the desk slightly away from walls to avoid possible wall damage
- Be sure power cords and other wiring are long enough to reach the lowest & highest desk positions

RESET CONTROL PADDLE BEFORE USE

1. Press the control paddle DOWN until the desk is in its lowest position.
2. Release the paddle.
3. Press and hold the paddle DOWN again until the display reads "RESET".
4. Release the paddle.
5. Press and hold the paddle DOWN again until the desk lowers a little bit more, slightly rises and stops.
6. Release the paddle.

Your desk is now ready to use!

Note: Resetting your keypad re-calibrates the columns and control box but will not delete height presets.



HEIGHT ADJUSTMENT

Manually adjust the height by pressing or raising the control paddle until the desired height is achieved.

PROGRAMMING DESK HEIGHT PRESETS

1. To program your favorite seated and standing position, start by using the paddle to position the desktop to the desired height.
2. Press the right side menu button two times. A heart and a 1 or 2 will appear, signifying that your position has been set. 1 = seated position; 2 = standing position
3. Tap the paddle to awaken it, then double-tap up or down to move the desktop to the programmed height.

LOCKING CONTROL PADDLE

Press and hold the left side lock button until the display shows a lock symbol, approximately 4 seconds. Repeat to unlock.

Press and hold the menu button to access further settings including min/max heights, collision sensitivity, and dimension preferences. See Owner's Manual.

Owner's Manual | www.bdiusa.com/luma-manual

Product Registration | www.bdiusa.com/register